

Installation Instructions

PVD gun metal
cold (right turn)
600-2106
hot (left turn)
600-2116

